

6.4 Termostaty chladničkové a mrazničkové

Termostaty – RANCO

Použití pro: CH – chladnička, CHO – chladnička odtávací, M – mraznička, N – nápojový chladič, P – průtokový chladič

Typ	Pracovní rozsah °C				Vypnutí defrostatu °C	Délka kapiláry mm	Registr. číslo
	minimum		maximum				
	zap.	vyp.	zap.	vyp.			
K 50 – H1104 CH	-4,5	-12,5	-12,0	-22,5	-	1 200	7065000.058
K 50 – H1107 N	+12,5	+8,5	+2,0	-3,0	-	2 000	7065000.057
K 50 – H2005 P	+14,0	-	-0,5	-2,5	-	1 450	7065000.060
K 50 – P1464 CH	-	-	-10,0	-17,5	-	1 300	7065000.065
K 54 – H1404 M	-12,0	-16,5	-	-31,0	-	2 000	7065000.053
K 59 – L1027 CHO	+5,0	-15,0	+5,0	-30,0	-	800	7065000.050
K 59 – P3131 CHO	+2,0	-15,5	+2,0	-26,0	-	2 000	7065000.063
K 59 – H2805 CHO	+5,0	-11,0	+5,0	-26,0	-	1 500	7065000.052
K 59 – H1312 CHO	+2,0	-12,0	+2,0	-23,0	-	900	7065000.064
K 59 – H1303 CHO	+4,5	-6,5	+4,5	-21,0	-	2 000	7065000.059
K 59 – L2198 CHO	+5,0	-7,0	+5,0	-23,0	-	2 450	7065000.066
K 61 – L1505 CHO	+3,5	-8,0	+3,5	-18,0	-	1 500	7065000.051

Termostaty – ATEA

Typ	Pracovní rozsah °C				Vypnutí defrostatu °C	Délka kapiláry mm	Registr. číslo
	minimum		maximum				
	zap.	vyp.	zap.	vyp.			
A 04 0088 M	-14,0	-	-22,0	-30,0	-	1 500	7065000.030
A 13 0212 CHO	+3,0	-10,0	+3,0	-25,0	-	800	7065000.031
A 13 0137 CHO	+3,0	-10,0	+3,0	-25,0	-	1 500	7065000.032
A 13 0432 CHO	+3,0	-10,0	+3,0	-25,0	-	800	7065000.034
A 03 0016 CHO	+3,0	-16,0	+3,0	-26,0	-	600	7065000.037

Termostaty – Danfoss

Typ	Pracovní rozsah °C				Vypnutí defrostatu °C	Délka kapiláry mm	Registr. číslo
	minimum		maximum				
	zap.	vyp.	zap.	vyp.			
077B6008 CHO	+3,5	-7,0	3,5	-23,0	-	2 000	7065000.104
077B6208 CHO	+3,5	-11,0	+3,5	-27,0	-	1 200	7065000.105
077B0816 N	+12,5	+8,5	+2,0	-3,0	-	1 600	7065000.106
077B6232 CHO	+3,5	-11,0	+3,5	-27,0	-	1 600	7065000.107
077B7006 M	-10,0	-24,0	-17,0	-34,5	-	2 300	7065000.108

